



**CB140**

**USER MANUAL**

**PRO-LIGHTING**

# WARNING

PLEASE READ CAREFULLY – EU and EEA (Norway, Iceland and Liechtenstein) only



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive ( 2202/96/EC) and your national law. This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (WEEE) . Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time , your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling , please contact your local city office , waste authority , approved WEEE scheme or your household waste disposal service. Contents and images shown on this manual can be changed without any notice. Please visit our website [www.soundsationmusic.com](http://www.soundsationmusic.com) to check latest version.

DESIGNED IN ITALY BY SOUNDSATION®



MADE IN CHINA

---

All the Trademarks are property of their respective owners  
SOUNDSATION® is a registered trademark of  
FREEXPORT SPA – Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy

**FREEXPORT**

© SOUNDSATION 2012 – All rights reserved – All total or partial reproduction of this manual by any other company or person without express authorization of SOUNDSATION is strictly forbidden.



## WARRANTY & SERVICE

All SOUNDSATION products feature a limited two-year warranty. This two-year warranty is specific to the date of purchase as shown on your purchase receipt.

The following cases/components are not covered from the above warranty :

Any accessories supplied with the product

Improper use

Fault due to wear and tear

Any modification of the product effected by the user or a third party

SOUNDSATION shall satisfy the warranty obligations by remedying any material or manufacturing faults free of charge at SOUNDSATION's discretion either by repair or by exchanging individual parts or the entire appliance. Any defective parts removed from a product during the course of a warranty claim shall become the property of SOUNDSATION

While under warranty period, defective products may be returned to your local SOUNDSATION dealer together with original proof of purchase. To avoid any damages in transit, please use the original packaging if available. Alternatively you can send the product to SOUNDSATION SERVICE CENTER – Via Enzo Ferrari , 10 – 62017 Porto Recanati - Italy . In order to send a product to service center you need an RMA number. Shipping charges have to be covered by the owner of the product.

For further information please visit [www.soundsationmusic.com](http://www.soundsationmusic.com)



Dear customer,

first of all thanks for purchasing a **SOUNDSATION®** product. Our mission is to satisfy all the possible needs of musical instrument and professional audio users offering a wide range of products using the latest technologies for a reasonable price.

We hope you will be satisfied with this item and, if you want to collaborate, we are looking for a **feedback** from you about the operation of the product and for possible improvements to introduce in the next future. Go to our website [www.soundsationmusic.com](http://www.soundsationmusic.com) and send an e-mail with your opinion, this will help us to build instruments ever closer to customer's real requirements.

One last thing: read this manual before using the instrument, an incorrect operation can cause damages to you and to the unit. Take care!

**The SOUNDSATION Team**



# GENERAL WARNINGS

**To prevent possible damages read the following list of actions:**

- Do not place the product in wet or dirty environments.
- Do not remove the protective coverings.
- Do not cover any of the products ventilation holes.
- Air must circulate freely around the product.
- Do not set the product on a surface with excessive vibration.
- Do not expose the product to high electro-magnetic interference.
- Do not expose the product to heat, cold, wet in improper way in respect to its IP grade
- Do not leave the product in direct sunlight.
- Do not expose the product to electrostatic forces.
- Do not place items with flames, such as candles or lighters, on the product.
- Do not place the product on anything containing water or other fluids.

If any foreign objects enter the instrument, please contact your dealer or an authorized **SOUNDSATION** center.

The **serial number**, electrical features and international standards are printed on a label located in the bottom of the instrument.

In case of problems remember to give the serial number to the responsible of the technical assistance.




PLEASE READ THESE INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE REFERENCE

This light system can be used as with a USB, to play your music, or just as a backing light system.

## Cautions & Warnings

- Only use this light system for its intended purpose. (Domestic use only)
- Connect the appliance only to an alternating current of the voltage specified on the rating plate & only to an earthed socket. To avoid circuit overload do not operate another high wattage appliance on the same circuit
- Never pull the cord to disconnect from the socket, always remove by grasping the plug.
- Do not lift the appliance by electric cord or supply hose
- Always disconnect the appliance from the socket when not in use
- Do not operate this appliance if the cord has been damaged or if it has been dropped, it must be inspected by a qualified person, (electrician) for examination and repair.
- Always keep the light system out of reach of children and always ensure that children are supervised when the system is switched on.
- During use always position the power base on a stable and even surface.
- Do not allow the power cord to touch the hot surface
- This light system is not to be used if it has been dropped, if there are visible signs of damage.
- This appliance is not intended for use by persons, (including children), with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety
- This light system can potentially trigger seizures for people with photosensitive epilepsy. Adult discretion is advised.

Instructions for use: Simply insert your USB into the port and press play!



## on Waste Disposal for Consumers of Electrical & Electronic Equipment

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE).

Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used.

For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge.

If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be helping to save valuable resources and preventing any potential negative effects upon human health and the environment, of any hazardous materials that the waste may contain.

